

Thermal Desorption Spectroscopy Studies of Hydrogen Retention on FLIRE


W. Olczak, R. Stubbers, D. N. Ruzic,
P. Brenner, T. Gray, B. Masters

*Plasma Material Interaction Group
University of Illinois at Urbana-Champaign*

*46th Annual Meeting of the Division of Plasma Physics
Savannah, Georgia, November 15-19, 2004*


Overview

- Brief overview of design of the Flowing Liquid Retention Experiment (FLIRE)
- Review Helium Retention and Diffusivity
- Thermal Desorption Spectroscopy (TDS) measurements of deuterium absorption in flowing lithium



FLIRE Design

- Two ramps with Li flow converge and form a vacuum seal between the upper and middle chamber
- Middle chamber monitored for prompt release
- TDS chamber used to release long-term trapped species, such as deuterium
- Middle chamber and TDS chamber share MS-RGA (gate valves isolate chambers)
- Lower reservoir pressurized to move lithium upper chamber
- Thermal Desorption Spectrometry (TDS) chamber can reach 1200C





Objectives of FLIRE

- Prior work
 - Demonstrated helium pumping with quantitative measurement of Helium retention in flowing liquid lithium, estimate diffusion coefficient
- Present work
 - Develop plasma source for higher implanted hydrogen flux in flowing lithium
 - H desorption kinetics measurements with lithium after plasma/beam exposure using thermal desorption spectroscopy
- Future Work
 - Revisit He work with plasma source
 - Retention and diffusivity measurements with other candidate liquid PFCs, such as tin or gallium
 - Design upgrade to FLIRE facility to accept pulse plasma gun and magnet assemblies



Thermal Desorption Spectroscopy (TDS)

- Lithium sample is heated linearly from 220 °C to 600 °C at 2° C/minute
- Magnetic Sector RGA (good low-mass sensitivity) looks at gas evolution in TDS tank
- Temperature at which deuterium peak is observed is correlated to deuterium concentration via phase diagram




Lithium Hydrogen System

- Phase diagram shows transition from $\text{Li(l)} + \text{LiH(s)}$ to only Li(l) for concentration $< 19\%$
- H is everywhere; deuterium (D) is used as traceable substitute
- D concentration can be determined by temperature at which peak desorption occurs





Flowing Lithium Neutral (molecular) Deuterium Exposure

- 7×10^{-5} Torr and 1 Torr deuterium pressure at 230 C
- Initial spike with temperature increase from 230 C - 250 C upon entering TDS chamber
- Immediate D_2 release from Lithium indicates low lithium-deuteride concentration ($\sim 0.2\%$)
- Similar results could be due to limited exposure time
- Try longer duration tests on lithium pool with static gas fill




Static Lithium Neutral (Molecular) Deuterium Exposure at 1 mTorr

- Static pool of clean fresh lithium at 350°C
 - Exposed to $\sim 1\text{mTorr}$ of deuterium gas for **10 minutes**
 - Cooled to 220°C and then ramped up to 600°C
- Desorption peak appears as HD and D_2 at 350°C , corresponds to the temperature of D_2 exposure and $\sim 0.7\%$ LiD
- Sample soaked at 600°C to clean up impurities





Static Lithium Neutral (Molecular) Exposure at 0.07 Torr

- Same lithium (cleaned by 600°C bakeout) at 350°C
 - Exposed to ~0.07mTorr of deuterium gas for 10 minutes
 - Cooled to 220°C and then ramped up to 600°C
- Again, desorption peaks appear at 350°C




Equilibrium

- Lines in phase diagram is not at constant pressure
- Lithium deuteride concentration is insensitive to exposure pressure in the single phase region
- Pressure required to reach two-phase region was not reached for long-duration exposures at 350°C
- If hydrogen (D/T) is **IMPLANTED** – a very high effective pressure – higher concentrations can be reached





Deuterium Plasma Exposure

- With divertor-plasma exposure, two-phase region may be reached, despite high temperatures and low pressures
- FLIRE provides a means of measuring deuterium absorption in flowing lithium – necessary data for designing a flowing lithium divertor
- Ion gun used for helium retention measurements is too weak for hydrogen measurements
- Need more intense plasma source to separate neutral gas contribution from implanted contribution




Simple Plasma Source

- Two-electrode DC plasma source
- Cathode is near ramp
- Cathode is grounded, prevents discharge throughout chamber
- Screened hole in cathode allows ion extraction
- In-situ probe monitors ion current to lithium continuously
- Operate source at low-enough pressure to avoid two-phase region – keeps absorption due to background gas low
- Plasma fills entire length of ramp from inlet to outlet





Plasma Source in Operation



clipped video 17.mpg

Prompt Release

- 180 mTorr of D_2 gas
- 800 V, 32 mA discharge (ion current needs to be calibrated)
- Flow speed ~ 20 cm/s
- As with helium measurements, a vacuum seal is maintained and prompt release is observed during the flow only
- TDS trace indicates a peak at 400-500 $^{\circ}C$
- Corresponding LiD concentration is 2-4%
- Much higher than previous flow measurements with only deuterium gas



Next Steps

- Additional neutral gas absorption experiments at varying pressures, flow rates and temperatures to fully characterize background gas absorption
- Additional deuterium absorption measurements with plasma source to verify absorption greater than neutral gas case
- Calibration of ion current from gun
- Estimate of fast atomic D flux on surface

Conclusions

- Neutral gas experiments reproduce points on Li/LiH phase diagram, confirming FLIRE's ability to quantify hydrogen retention in flowing lithium
- Neutral gas experiments also suggest that absorption of background deuterium (required to operate plasma source) will not lead to two-phase region – background gas absorption should be limited to low levels allowing effect of plasma to be isolated from background gas
- Plasma exposure seems to lead to higher hydrogen retention, as expected
- More data with FLIRE's plasma source is needed to verify and quantify higher retention

Acknowledgements

- NPL Associates
- US Department of Energy
- Dan Schulz
- Joe Mestan
- Patrick