

## Status: Tritium Plasma Experiment at the INL Safety and Tritium Applied Research (STAR) Facility

R. A. Anderl\*, J. P. Sharpe\*, R.D.  
Tillotson\* (\*INL)  
R.A. Causey<sup>+</sup>, C.L. Kunz<sup>+</sup>,(+SNL)

Session 5 Presentation at  
Plasma-Facing Components Meeting  
May 9-11, 2005  
Princeton, NJ

# Outline

- Re-assembly/installation activities
- System integration/testing activities
- Plans for initial plasma operation and experiments

## Tritium Plasma Experiment (TPE)

Steady-state plasma generator

Tritium and Be compatible


Plasma density:  $10^{19} / \text{m}^3$

Plasma ionization fraction: 1-10%

Ion flux:  $10^{19}$ - $3 \times 10^{22} / \text{m}^2$


Ion energy: 15-200 eV

Target temperature: 100-800°C



# TPE is located in the STAR Facility

## STAR Floor-plan Layout



15,000 Ci tritium limit  
 Segregation of operations/ventilation  
 Once-through room ventilation  
 Gloveboxes and hoods  
 Tritium cleanup system (TCS)  
 Tritium storage and assay system (SAS)

# TPE Re-assembly, Setup and Operation

- **Re-assemble** TPE in HEPA-filtered ventilated room
- **Install utility services** for TPE system in PermaCon room
  - Electrical, water, gas, effluent control,  $^3\text{H}$  monitoring
- **Interface** TPE system to STAR utility services
  - **Electrical**, coolant systems, **glovebox ventilation**, TCS
- **Check** TPE components, update and test
  - **Vacuum pumps**, **pneumatic valves/lines**, **control instrumentation**, **water lines**, **plasma source**, **power supplies**, **heaters**, **gas flow cont.**
- **TPE system integration and testing**
  - Establish system vacuum; operate control instrumentation, power supplies, coolant and gas systems, and plasma source
  - Initiate plasma operation with hydrogen
- **Initiate TPE experiments** with hydrogen/deuterium plasmas
- **Prepare** for operation with tritium
  - **Glovebox testing**, purge gas control, TCS interface, **U-bed installation**,  **$^3\text{H}$  source**
- **Prepare** ISMS documentation and procedures

# TPE is in a HEPA-filtered ventilated room





PermaCon enclosure housing  
TPE and ancillary equipment





Auxilliary blower and HEPA filter  
for room ventilation.



# Utility services for TPE



# Distribution of utility services inside the PermaCon





# Plans and schedule for TPE set up and operation

- **Complete TPE interface to utility services (May-05)**
  - Component coolant system
- **Complete testing of TPE components (May/June-05)**
  - Pneumatic & water lines, coolant systems, control instrumentation, power supplies, plasma source, heaters, gas flow controllers
- **Complete system integration & testing (June/July-05)**
  - Establish system vacuum, integrated operation of all systems, initiate plasma operation with H
- **Initiate TPE experiments: H or D plasmas (July-05)**
- **Complete preparation for  $^3\text{H}$  operation (Sept.-05)**
  - Glovebox testing, TCS interface, U-bed install
- **Complete ISMS documentation and procedures for initial tests (June/July-05)**