

Development of Heat Transfer Diagnostics for ALPS

Sandia
Team

Richard Nygren, Dennis Youchison, Jim McDonald,
Tina Tanaka, Tom Lutz, Ken Troncosa,
Mike Ulrickson

ALPS-HT
Team

Sandia, ANL, UCLA
others (overlap with APEX)

Work in progress:

- preparation of liquid metal loop for EBTS
- preparation of heated Li pool for EBTS
- preparation for IR measurements on Li

ALPS Meeting
8-9 May 2000, Argonne National Laboratory



ALPS - Power Density

MHD suppresses turbulence in liquid metal.

A critical issue for liquid metal PFCs is how to increase the transfer of heat from the heated surface to the bulk fluid, as by 2-D turbulence or internal rotation in droplets.


In PFCs for APEX and ALPS, developing flow from nozzles is important.

Modeling these effects is a challenging computational problem.

The most productive approach is likely a combination of testing and analyses. For both, we need to develop tools.

Analysis: 3-D models, MHD effects in developing flows.

Tests: techniques to measure surface temperature distributions in fast moving fluids.



- *The full 3-D MHD analysis of a divertor or experiment is difficult.*
- *A “complete” heat transfer experiment is large and expensive.*

“Full” Conditions:

vacuum
 free surface flow ($v > 10 \text{ m/s}$)
 heat (neutral beam)
 heat rejection (HX)
 $B > 3 \text{ T}$ (s.c. magnets)

MHD issues:

developing flow
 (inlet/outlet, bends, ∇B)
 nozzle model
 2-D turbulence
 turbulence enhancement


Measurement issues:

fast moving surface
 spatial resolution ($s = 1 \text{ mm}$)
 time resolution ($s/v < 100 \mu\text{s}$)
 emissivity ($\epsilon > 0.1$, IR software)


Approach:

- tools for MHD calculation
- appropriate diagnostics


*Find a “good way” to do simple heat transfer tests.
 Proceed to larger experiments.*



Heat Transfer & Thermal-Hydraulics for ALPS



Develop Measurement Techniques



heater element with
support and standoff

thermocouple
(in SS boat)

Objectives:

calibrate IR image
compare test with
FE thermal model

Materials:


Ga pool (1999)

Sn pool (1999)

Li pool, new boat (2000)

316SS boat

“black hole” for IR calibration
recess on bottom for heater



Sandia
National
Laboratories

Prepare Li Loop for EBTS







Photo of chamber

- Chamber is ready and will be used for Li pool test
- Bids are being negotiated for Li loop (heated pot, pump, piping, collection basin, vacuum and controls)
- Nozzle and catcher system is in development.



Sandia
National
Laboratories

Prepare Li Loop for EBTS



• We started with a design by JAERI and Osaka U. for a Li loop for IFMIF testing.

- We made a polished plexiglass model. (Reservoir was packed with tubes to provide flow straightening.)
- In our initial tests, streamlining with the nozzle cross section was lost in <10cm.
- We hope to collaborate with UCLA on an improved nozzle design.

Calibration & Calorimetry: A Challenge for LM Surface Heating Experiments

3mm Sn drop/stream/film passes through a 20mm thick SOL at 10m/s (1ms) and absorbs 20MW/m².

A **droplet** absorbs ~0.14J. T_{bulk} (thermalized) rises **44°C**.

A **stream** absorbs ~2.4J. T_{bulk} (thermalized) rises **9.4°C**.

For a **film**, T_{bulk} (thermalized) rises **7.4°C**.

We want to measure temperature distributions.

In a **droplet** or **stream** ejected from a nozzle,
spin affects the surface heat distribution.

In a **droplet** or **stream** or **film**,
turbulence (2-D) affects the heat flow.

Calibration & Calorimetry: A Challenge for LM Surface Heating Experiments

Basic features:	flow velocity, \underline{v}	5-20 m/s
	spatial resolution, \underline{s}	1-2 mm
	desired acquisition time $>.5\underline{s}/v$	50-100 μ s
	IR TV raster, $f = 30$ frames/s,	$1/f=33$ ms
	IR line scan mode, $f = \sim 1800$ line/s	$1/f=\sim 500\mu$ s

We are planning heating tests with streams/ramps and droplets (no B-field) to develop thermal measurement techniques.

We are exploring possibilities for future tests with B-field.