



# Experiments for Heat Transfer Diagnostics: IR Emissivity Issues

ALPS e-Meeting

May 4, 2001

T. Lutz, J. McDonald, T. Tanaka,  
R. Nygren, M. Ulrickson



Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company, for the United States Department of Energy under contract DE-AC04-94AL85000.

slide 1





***Measurement and interpretation of surface temperatures of low emissivity surfaces is by no means straightforward.***

**Objective: Develop working systems to measure the surface temperatures of flowing liquid surfaces.**

- ✓ measure surface temperatures in static liquid metal pools; identify issues and develop useful techniques**
- build and operate a flowing liquid (Li) metal loop**
- measure surface temperatures of flowing liquid metal**
- collaborate with others on heat transfer experiments**
- collaborate with others in preparing LM modules for experiments in confinement devices (NSTX, C-MOD,...)**



## IR diagnostic error sources



- **Surface**
  - **reflections of other sources (direct and secondary)**
    - chamber wall reflectivity
    - filaments and heaters
    - plasma facing components
  - **variations**
    - contamination
    - phase change
- **Optical path**
  - diagnostic window transmission
  - gas / vapor absorption
  - ionized gas / vapor emission (e.g. Li emission at  $2.44\mu\text{m}$ )



# IR Diagnostics Experiments

- **Gallium**
  - Vacuum
  - Argon cover gas with windows
  - Argon cover gas without windows
- **Lithium**
  - Vacuum (data reported with estimated window transmission correction)
- **Drude Emissivity Calculations**
  - Based on free electron model ( $\epsilon=f[R_H, \rho_e, \theta, \lambda]$ )
  - Wavelengths of detectors 2, 3, 3.9, 5  $\mu\text{m}$
  - Temperature range 30-390 C

# Test Configuration



Top View




## Instruments to Characterize Surface and Bulk Temperature

<i>Name</i>	<i>Temperature range (°C)</i>	<i>Wavelength (μm)</i>	<i>Emissivity Range</i>	<i>Windows</i>
<i>Pyrometer (IRCON)</i>	70–220	2–2.6	0.001 – 0.999	Sapphire
<i>Pyrometer (Landmark)</i>	130–550	2.05–2.55	0.1 – 1.0	ZnSe and WF Quartz
<i>Pyrometer (IRCON)</i>	300–1300	4.8–5.3	0.1 – 1.0	ZnSe and Sapphire
<i>Infrared camera (Inframetrics)</i>	25–500+	2-14 with 3.9 filter	1.0	ZnSe and NaCl, later, LW Quartz
<i>Thermocouple (Type K)</i>	0–1000	N/A	N/A	N/A



## Gallium Apparent Emissivity

Argon cover gas  
(no correction for gas absorption)




slide 7




## Gallium Apparent Emissivity

Argon cover gas  
(no correction for gas absorption)




slide 8






## Gallium Corrected Emissivity and Window Transmission Factor Mid Range Pyrometer (2.05-2.55 microns)



slide 9




## Emissivity of Lithium using Drude Model 40 degree angle of incidence



slide 10



## Liquid Lithium Emissivity Corrected Data (estimated window transmission correction)



slide 11



# Conclusions

**Commercial instruments may be usable for liquid metal temperature measurements with proper precautions and corrections.**

**Because liquid metals have such low emissivity, we need to:**

- **control background IR radiation (reflections of other sources)**
- **determine and correct for transmission factors for windows, gasses and vapors**
- **control or account for contamination of liquid metal**



# Future Work

- **emissivity measurements**
  - **Lithium and Tin**
  - **apply Gallium window transmission corrections to previous Lithium experiments**
- **build and operate a flowing liquid (Li,Sn) metal loop**
  - **emissivity measurements of flowing liquid metals**
    - **Lithium**
    - **Tin**
  - **application of heat flux with electron beam**
- **collaborate with others on heat transfer experiments**
- **collaborate with others in preparing LM modules for experiments in confinement devices (NSTX, C-MOD,..)**